

Mega Pizza Stone

Pierre à pizza Mega

Piedra para pizza Mega

SIS7000



WARNING:

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS ON THIS SHEET AS WELL AS THE INSTRUCTIONS AND WARNINGS IN YOUR GRILL OPERATOR'S MANUAL BEFORE USING THIS PRODUCT.

Failure to follow all instructions and heed all warnings may result in electric shock, fire and/or serious personal injury.

Make brick oven-quality pizza on your grill. The Mega Pizza Stone fits 22-1/2 in. STÖK grills, and most other 22-1/2 in. kettle-style grills.

Follow all instructions in your grill Operator's Manual as well as the instructions provided on this sheet when using the Mega Pizza Stone.

USING THE MEGA PIZZA STONE

See Figures 1 - 2.

WARNING:

The Mega Pizza Stone may be heavy for some operators.

Use caution when placing or removing the pizza stone from the grill to prevent serious personal injury.

- Do not remove the existing cast iron grate and insert unless the grill is completely cool.
- When using a charcoal grill, light the charcoal following manufacturer's instructions, and wait for flames to go out before installation.

NOTE: Clean Mega Pizza Stone prior to use. It is not recommended to use soap or detergent.

WARNING:

After placing the Mega Pizza Stone on the grill, do not remove until it is completely cool. Failure to heed this warning may result in serious personal injury.

- Using heat-resistant oven mitts, set the wire tray and Mega Pizza Stone into the grill firebox. The handles will slide off the sides of the wire tray and out of the way, if desired.
- Allow the Mega Pizza Stone to cool completely before using the wire handles to remove it from the grill.

OPERATING TIPS

- The Mega Pizza Stone will darken, naturally season and develop a nonstick surface over time with use.
- The Mega Pizza Stone is durable, but it may break or chip if dropped, handle it carefully.
- Avoid extreme temperature changes to prevent breakage from thermal shock.
- Preheat the stone for approximately 20-30 minutes and cook pizza as directed in recipe.
- When finished cooking, carefully remove the pizza. Wear heat-resistant oven mitts and use a pizza peel or other long-handled utensil.

CLEANING THE MEGA PIZZA STONE

- Allow the grill and the Mega Pizza Stone to cool completely, then remove the stone from the grill.
- Use a plastic utensil or scraper to remove excess food. Rinse with water when desired, but do not soak.
NOTE: The Mega Pizza Stone is not dishwasher safe.
- When not in use, store the Mega Pizza Stone in an enclosed area where it will not be exposed to the elements.

CALIFORNIA PROPOSITION 65

WARNING:

Combustion by-products produced when using this product may contain chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm. To reduce the risk of exposure to these substances, always use the grill in a well-ventilated area. This product contains chemicals, including lead and lead compounds, known to the State of California to cause cancer, birth defects, or other reproductive harm. **Wash hands after handling.**




Fig. 1




Fig. 2